


STEP-1: Keep Bottom Tray upside down on a soft surface to avoid scratches. Fix the Wheels on the Bottom Tray by positioning the Wheel Caps along with the holes on the Bottom Tray and pushing inside.



STEP-2: Fix the Right Side Panel and Left Side Panel on the Bottom Tray by positioning the pipes along with the holes on the Bottom Tray and pushing the pipes inside one by one.



STEP-3: Fix the Front Side Panel by sliding between side panels in the center and pushing into the bottom panel.



STEP-4: Fix the Top Cover on the Top by positioning the holes along the pipes and pushing inside.



STEP-5: The assembled All-In-One Plastic Container is ready for use.



SINGLE BATTERY | DOUBLE BATTERY |
JUMBO BATTERY | FLAT PLATE BATTERY | TALL TUBULAR BATTERY

MICROTEK




PLASTIC CONTAINER EXTENSION

ALL-IN-ONE


FOR

ASSEMBLY INSTRUCTIONS


STEP-1: The assembled All-In-One Plastic Container is ready after assembly.



STEP-2: Keep Extension Tray upside down on a soft surface to avoid scratches. Fix the Wheels on the Bottom Tray by positioning the Wheel Caps along with the holes on the Extension Tray and pushing inside.



STEP-3: Fix the Extension Tray by positioning on back bottom side of the All-In-One assembled Plastic Container along with the slots on the Bottom Tray and pushing the pipes inside.



STEP-4: The assembled All-In-One Plastic Container with Extension is ready for use.



SINGLE BATTERY | DOUBLE BATTERY

JUMBO BATTERY | FLAT PLATE BATTERY

TALL TUBULAR BATTERY

